




User Manual

[MD-400D 3D Printer]

*Please read this guide carefully before using this printer



Shenzhen MINGDA Technology Co.,Ltd

V1.1

Contents

Cautionary Notes	1
1 Overview	2
2 Device Introduction	2
Device Parameters	2
Packing List	3
3 Operational Steps	4
Unboxing Inspection	4
Device Installation	4
Install the warning light	4
Install the antenna	4
Power on	5
Power off	5
Startup Configuration	6
Select Language and Time Zone	6
Auto Bed Leveling	6
Wi-Fi	6
Introduction to machine operation page	8
Extruder Offset Calibration.....	12
XY Axis Offset Calibration	12
Z Axis Offset Calibration	13
Install the filament.....	14
How to unload filament	16
Resume printing after power failure	17
Slicing Software Installation and Usage	18
Installation	18
Configuration	18
Usage	19
Printing	20
Local Printing	20
LAN Printing	20
Print Mode	23
Copy Mode	23
Mirror Mode	24
Print Two Colors	25
Printing Support	27
Printing	28
4 Maintenance and Care	29



Thank you for choosing MINGDA Technology's products!

For the best experience, please read this user manual carefully and follow the instructions to operate the printer. If you encounter any issues with the printer, please contact us using the contact information provided at the end of this user manual. Our team is always ready to provide you with high-quality service.

To enhance your usage of our product, you can also learn how to use the printer through the following means:

1. User Manual: Relevant instructions and videos can be found on the included USB drive.
2. You can also visit our official website (www.3dmingda.com) for information on software, hardware, contact details, device instructions, device specifications, and warranty information, among other things.

Cautionary Notes

1. Please do not place the printer in environments with significant vibrations or instability, as machine shaking can affect the print quality.
2. Avoid touching the nozzle and heated bed while the printer is in operation to prevent potential burns from high temperatures, resulting in personal injury.
3. Refrain from moving the device during the printing process to prevent accidents and injuries.
4. Do not dismantle the equipment or alter circuit settings without authorization.
5. Avoid using the device in high-temperature or humid environments to prevent compromising device performance or creating safety hazards.
6. In case of an emergency, immediately cease using the device and power it off.

1. Overview


This manual provides instructions on the usage of the 3D printer, covering aspects such as an overall introduction to the device, operational procedures, maintenance, and care. The aim of this manual is to assist you in correctly using and maintaining the 3D printer, ensuring device performance and safety, extending the lifespan of the equipment, and enhancing print quality. We hope that you follow the requirements and recommendations outlined in this manual during usage, and maintain attention to and care for the equipment. Thank you for choosing our product, and we wish you a pleasant experience!

2. Device Introduction

Device Parameters

Basic Parameters	
Product Model	MD-400D
Machine Dimensions	690*790*910mm
Max. Build Dimensions	400*400*400mm
Duplicate Mode	400(2*200)*400*400 mm
Mirror Mode	320(2*160)*400*400 mm
Print Technology	Fused Deposition Modeling (FDM)
Rated Voltage	100-240V, 50/60Hz
Rated Power	800W
Ambient temperature	10°C-30°C / 50°F-86°F
Extruders	Two
Max. Nozzle Temperature	350°C
Max. Bed Temperature	110°C
Screen	7inch touch screen
Printing Method	USB Flash Disk / LAN Printing
Connection	USB Flash Disk / WIFI / Ethernet
Power Loss Recovery	Yes
Filament Detection	Yes
Fast Auto leveling	Yes
Camera	Yes
Fast Calibrate Offset	Yes
Supported Filament	Common filament: PLA, TPU, PETG; Engineering filament: PA-CF/GF, PET-CF/GF, HtPA-CF/GF, ABS-GF25, ABS-CF20, PA-GF25/CF25; Support filament: S-Mulit, S-HtPA, PVA, etc

Packing List



Tool List



U-disk




Nozzle*2



Diagonal pliers




7mm Sleeve



Auxiliary
calibration board



Power cable



(1.5 / 2.0 / 2.5 / 3.0 / 4.0)

Allen wrench



Warning lights



Antenna

Note: The 400D is equipped with a hardened steel nozzle. If you frequently print high-temperature materials, long-term printing will cause wear to the nozzle. We recommend replacing the nozzle every 500 printing hours.

3. Operational Steps

Unboxing Inspection

Unpack and inspect the device for any damage. If there is any abnormality, please contact the manufacturer or dealer.

Device Installation

1. Install the warning light.




2. Install the antenna.



3. Power on

Please ensure that the print platform is clear before connecting the power and check if the device is connected properly.

In a good ventilation and dry environment




Insert a power socket, Press the switch




Press the power button to turn on the printer

4. Power off

When you turn off the printer, please don't press the power button directly! Check the Page 10, click "General-System-Shutdown-Printer" to turn off the printer



Click the "General" button.




Click the "System" button.




Click the "Shutdown" button.

Startup Configuration (For the first startup, it will enter the configuration wizard.)

1. Select Language and Time Zone




Click the right arrow to choose the language, and click the upper right arrow to proceed to the next step.




Start by selecting your continent on the left, then click the right arrow to choose your specific region. [Time zone settings will take effect after connecting to Wi-Fi and restarting the system.]

2. Auto Bed Leveling




Click the "Calibrate" button to initiate the quick auto bed leveling process, which will take approximately 3 minutes. Please be patient.




Click the "Save" button to store the bed leveling data and automatically restart the printer.


3. Wi-Fi



Click the right arrow button, select the network you want to connect to. The first connection may take some time, please be patient. If the network is not displayed for an extended period, click the refresh button at the top.



Enter the network password and then click Save.




Once the connection is successful, click the Close button.



Upon successful connection, click the checkmark in the upper right corner to enter the main interface of the machine. If you do not need to connect to the network, you can also click the checkmark to skip this step.

After completing the above steps, Home all Axis




Click the "Move" button




Click the "Home" button

Z Calibrate




Click "Setting-Z Calibrate"




Click "Start", wait Z axis calibrating and click "Accept" and confirm

Introduction of machine operation page




	Primary interface	Explain
01	Temperature	Temperature display area.
02	Time	Time display.
03	Move	Adjust the value of the XYZ axis.
04	Preheat	Pre-set nozzle & hotbed's temperature.
05	Extrude	To unload or load filament.
06	Settings	Printer's printing value adjustment.
07	General	More printer setting.
08	Print	Start printing.
09	Stop	Emergency stop button.
10	Homepage	Return to the main page.
11	Return	Return to the previous page.

Settings:




	Secondary interface	Explain
01	Leveling	Auto-leveling
02	Z Calibrate	Calibrate Z offset
03	Fan	Cooling fan adjustment
04	Leds	Turn on/off Light
05	Save config	To save your configuration
06	KlipperScreen	Includes some basic settings such as time, language, screen timeout, notification sound toggle, and automatic shutdown after printing completion.
07	Network	To connect Wi-Fi
08	Print Mode	Select Copy Mirror or Autonomous Mode

General:



	Secondary interface	Explain
01	Manual	Manual
02	Troubleshooting	Troubleshooting
03	Cautions	Cautions
04	Maintenance	Maintenance
05	Calibration	Contains some basic test models, which can be selected to test the corresponding functions.
06	XY Offset	Calibrate XY axis
07	Z Offset	Calibrate Z axis
08	System	Check next page

System:




	Secondary interface	Explain
01	Full update	Update all content available for update on the current page
02	Reset	Reset to Factory Defaults
03	Refresh	Refresh the current page to check for updates, in conjunction with the use of 'Full update'.
04	Restart	Restart the printer
05	Shutdown	Turn off the printer, click Shutdown-Printer

Extruder Offset Calibration


XY Axis Offset Calibration

Tips:


Wipe the nozzle clean before calibration to avoid any interference during the process.




Remove the PEI sheet first, the camera was covered with PEI.




Put the Auxiliary calibration board in the center of platform




Click the "General" button.




Click the "XY Offset" button.




Click the "Start" button, and the left extruder will move to the calibration camera's position.



Fine-tune the XY axis to align the nozzle center of the left extruder with the origin of the XY axis. Click "Confirm Pos" to confirm the position of the left extruder. Meanwhile, the right extruder will move to the calibration camera's position.



Fine-tune the XY axis to align the nozzle center of the right extruder with the origin of the XY axis. Click "Confirm Pos" again to confirm the position of the right extruder.




Click the "Save" button to save the XY offset of the right extruder relative to the left extruder.


After finishing, don't put the PEI Sheet back to platform immediately. Please finish the Z offset first.

Z Axis Offset Calibration

Tips: Wipe the nozzle clean before calibration to avoid any interference during the process.




Click the "Z Offset" button.




Click the "Start" button to begin the automatic calibration. Initially, the left extruder will move to the top of the Z axis calibration sensor and slowly descend to trigger the switch. It will then automatically switch to the right extruder, repeating the same motion as the left extruder.



After the automatic calibration is complete, click the "Accept" button to save the Z-axis offset value.




While calibrating the Z-axis offset, the extruder will move towards the sensor button located the left side of the camera.

Safety Reminder: To ensure that the nozzle correctly lands on the sensor, please calibrate the XY axis before calibrating the Z axis. While the extruder is moving downward, pay close attention to its movement. If there is excessive deviation or signs of extreme extrusion pressure, click the return button in the top left corner of the screen or the emergency stop button  in the bottom left corner to stop the calibration. Contact customer support or refer to official videos for troubleshooting solutions.

Install the filament

(Take PLA filament as an example)


1. Hang two volumes of PLA Filament on the scraping pole in the left and right Filament box, and insert the Filament from the inlet port until the Filament are exposed to the printed head along the guide pipe.




2. You can directly pull out the guide tube upwards, pull the handle of the inlet port, insert the Filament into the squeeze machine into the material mouth.




3. Load Filament for the Left and Right Extruders




Click the "Extrude" button




Select the first extruder "T0", Click '100mm', click on the feed speed '5mm/s', then click 'load' to import the filament.



Sequentially load filament for the left and right extruders. If the temperature is too low, a prompt will appear indicating the need for heating. Click "Accept," wait for the nozzle temperature to reach 240°C, and then click the "Load" button to feed the filament.



Switch to the second extruder "T1", Repeat the steps of the first extruder.




After the completion of loading filament for "T1," it is necessary to click on the "T0" icon again. Failure to do so may result in collisions during subsequent movement commands for the extruder.


4. After the filament feeding is completed, Insert the large catheter.




How to unload filament




Click the "Extrude" button



Heat the hotend which was wanted to unload filament up to 240°C.
T0 is left hotend, T1 is right hotend.



Using the T0 hot end as an example, select T0 first. then set "Distance mm" as 25, "Speed mm/s" as 5, and click "load" once.




After finishing, quickly set "Distance mm" to 100, and click "unload" once. Wait for 6-7 seconds, and the filament can be taken out from the extruder.




Resume printing after power failure


When the printer is in the midst of the printing process, power outages may occur at times. This printer is equipped with a resume printing function to assist you in resuming the print from the point of interruption.



After power is restored, the printer will prompt whether to resume printing.



After clicking 'Confirm,' the printer will begin the preheating process on the Picture 2, continuing until the specified temperature is reached.



After reaching the specified temperature, the printer will automatically transition to the printing interface.

Slicing Software Installation and Usage

Note: Copy the data from the USB drive to your computer for backup.

Our company's slicing software is designed to work seamlessly with our machines to meet customer requirements.

Installation:


Search "<http://www.3dmingda.com/download>" in the Browser.

Download "MINGDA Orca Slicer" in this page


Configuration:



Upon the first run of Mingda OrcaSlicer, you will enter the configuration wizard.




Choose the MD-400D model and click "Confirm."




Select the desired filament type.

Usage

Click the "Prepare" button.



Choose the printer model and select the print material settings.




Load the STL model, adjust the print parameters. Once you confirm everything is correct, click the "Slice plate" button to slice the model.

Finally, click "Export G-code file" to save the file.


Printing




Local Printing



Insert the U-disk, then click the "Print" button.



Find the folder and Click the arrow on the right




Select the test gcode which was preset in the U-disk.




LAN Printing

Ensure that the printer and the computer host are on the same local network.




Click "Settings" to enter the settings page.



Click "Network" to enter the network page.





Check the printer's IP address.




In Mingda OrcaSlicer, click the WiFi icon, select Host type as Octo/Klipper, enter the printer's IP address, and press Enter. Click the "Test" button to verify the successful connection.

File Transfer:




Click the dropdown icon  in the top right corner , select "Print."




Click "Print" and choose "Upload and Print."

Device Connection

After successful connection, click on "Device"



Enter the control interface below the diagram



1. **Task List:** Drag G-code files to this task list for printing.

2. **Temperature Control:** Displays machine temperature changes and allows pre-setting nozzle and bed temperatures.

3. **Camera:** Monitors the printing status.

4. **Movement Control:** Controls the movement of each axis and allows compensation settings after leveling.

5. **Printer Limits:** Controls the maximum acceleration of the printer, usually doesn't need to be changed.


6. **Console:** Sends G-code commands to run the machine and displays error output.

Print Mode

Copy Mode


Print Size: X * Y * Z: (2*200) * 400 * 400mm

In duplication mode, select the [MingDa 400D with a 0.4mm nozzle \(Left\)](#) for slicing. The models should be placed on the left side and not exceed the centerline of the platform, as shown in the image.




In the printer interface:


Note: After the printer restarts, it will default to Auto-park Mode.




Click the "Settings" button on the screen.



Choose "Print Mode."




Select "Copy Mode." A message will indicate a successful switch.



Return to the main interface, select "Print."



Insert the U-disk.




Choose the print file for printing.

Mirror Mode


Print Size: X * Y * Z: (2*160) * 400 * 400mm

In mirror mode, select the **MingDa 400D 0.4mm nozzle (Left)** for slicing. Place the models on the left side, ensuring they do not exceed the red area on the platform in the image to prevent nozzle collisions.




In the printer interface:


Note: After the printer restarts, it will default to Auto-park Mode.




Click the "Settings" button on the screen.



Choose "Print Mode."




Select "Mirror Mode." A message will indicate a successful switch.



Return to the main interface, select "Print."



Insert the U-disk.




Choose the print file for printing.

Print Two Colors

Printing size: 400 * 400 * 400mm


Selecting the [MingDa 400D 0.4 nozzle \(Dual\)](#)



1. In the filaments column on the left side of the interface, click "+" to add another filament.
2. Choose and modify the filament information.
3. In the Process section, click to switch to the "Objects" option.
4. Click on the color box next to the STL file to select the desired filament.

In the printer interface:


Note: When printing dual-color models, the printer will automatically switch to Auto-park Mode.



By default, it is in "Auto-park Mode"; select "Print."



Insert the U-disk.




Choose the print file for printing.

Double extrusion: Start the Prime tower

Because there is always one printer in standby mode during the printing process, it is easy to cause defects such as wire drawing and material leakage. Prime tower can solve this problem, the extruder will print a prime tower before each layer printing. Any material leakage will be printed on the tower, effectively avoiding the phenomenon of material leakage when replacing the extruder.

If you want to print the following two modes, we recommend adding this option to your Gcode.




1. Select the "Global" section.
2. Select the "Others" section.
3. Check the "Enable" option in the "Prime tower" settings.

Note: The printing position of the Prime tower cannot coincide with the model

Printing Support

Printing size: 400 * 400 * 400mm

Selecting the [MingDa 400D 0.4 nozzle \(Dual\)](#)



1. On the left side of the interface, in the filaments column, click "+" to add another filament.
2. Choose and modify the filament information.
3. Then, select the "Support" section.
4. Check the "Enable support" option.
5. In the "Filament for Supports" option, choose the filament needed for supports.
6. Click "Slice plate" to preview.

Note: When printing models with supports, the printer will automatically switch to Auto-park Mode.

In the printer interface:




By default, it is in "Auto-park Mode"; select "Print."


Insert the U-disk.

Choose the print file for printing.

Printing



Open the settings interface in the Printer tab, and check 'Auxiliary Part Cooling Fan' under "Basic Information-Accessory".



Due to the different feature of filament, if you do not need an auxiliary fan or need to adjust the fan speed, please go to the Filament tab, open the settings interface, and choose Cooling-Auxiliary Part Cooling Fan. Adjust the Fan Speed as needed.

4. Maintenance and Care

Cleaning the Nozzle: After printing is complete, promptly clean the residue on the nozzle using a tool and taking advantage of the nozzle's residual heat. Avoid touching the nozzle directly with your hands to prevent burns.

Replacing Filaments: Timely replace filaments based on the type and actual usage. It is recommended to use filaments recommended by the manufacturer. Seal filament not in use for an extended period, as excessive exposure to moisture in the air can make the filament brittle.



Checking the Platform: Regularly check if the print platform is flat. If there is deformation or damage, contact the manufacturer or dealer for repairs.

Regular Lubrication: Periodically apply lubricating oil to the lead screw and guide rails. During the operation of the printer, friction between various parts occurs. Without proper lubrication, it can lead to wear and damage.

Software Updates: Regularly update the printing software to improve print quality and efficiency.

Replace the hot end

1. Remove the screws on both sides of the print head cover (a total of 4);
2. Unplug the connecting terminal on the hot end and loosen the top wire that fixes the hot end;
3. Remove the entire hot end;
4. Insert the hot end that needs to be replaced, tighten the top screw when it is in place, and then plug in the connecting terminal.
5. Install the print head cover and circuit board protective cover



Note: After replacing the hot end, it is necessary to recheck the deviation values of the left and right heads. If the deviation is too large, it needs to be recalibrated



Shenzhen MINGDA Technology Co.,LTD
www.3dmingda.com



Shenzhen MINGDA Technology Co., Ltd



Official Website



Customer Support

Tel: 0086-13530306290

Email: support@3dmingda.com

www.3dmingda.com

Address: No. 20, Dahe Industrial Zone, Longhua District,
Shenzhen, 518110, Guangdong Province, China.