


I : Download excel Templates



II: Edit excel

“Sheet” indicates the inverter filled in in step 2.

“String” indicates the string name.

“Input Type” can be selected from the drop-down list (Note: double input requires two lines).

“MAC ID” is the MAC ID of the optimizer.

“Module” entered in step 2 can be selected in the drop-down list.

#	A	B	C	D
	组串 (String)	单/双输入 (Input Type)	优化器 (MAC ID)	组件 (Module)
2	String-A	双输入 (Honeybee800/1600)	69000001	正信四联_1 260
3	String-A	双输入 (Honeybee800/1600)	69000001	正信四联_1 260
4	String-A	双输入 (Honeybee800/1600)	69000002	正信四联_1 260
5	String-A	双输入 (Honeybee800/1600)	69000002	正信四联_1 260
6	String-B	单输入 (Honeybee350/400/650/850)	10123110	正信四联_1 260
7	String-B	单输入 (Honeybee350/400/650/850)	10123110	正信四联_1 260
8	String-B	单输入 (Honeybee350/400/650/850)	10110113	正信四联_1 260
9				
10				
11				
12				
13				
14				
15				
16				
17				

At the bottom of the spreadsheet, the formula bar shows: `D4_1|500` e.g. InverterLabel|PeakPower

III: Upload excel spreadsheet

