









opk Perfect Slim System Stacking 3 Doors -Fixed the belt with screw-Installation Instruction


Single Door 1&2




Middle Door




– Door opening sectional view



Door opening top view




Three Linkage Door (Right Opening) Accessories Diagram




Movable door2

Linkage door1


Movable door1



Bottom View



Three Linkage Door (Left Opening) Accessories Diagram




Movable door 2

Linkage door 1



Movable door 1

Bottom View




1 Cutting-belt Install the belt accessories

According to the thickness of the door, confirm the use of belt mold (40, 45)



Flush the belt with door frame, then cut the belt.

4 Cut the belt after flushing the door frame, and cut the belt one more tooth




6 Fix

The belt should be in alignment

5

I





The belt should be in alignment

2 Cut the Profiles Disassemble the Profiles



Profile 1

! Cutting from the uneven side of the profiles





Profile 2


! Cutting from the uneven side of the profiles




3 Install Rollers and Activators






4 Install the Top Track







5 Install the Covers of Track








6 Install the Covers of the Tracks



7 Install the door panel





8 Install the door panel accessories








9 Install the belt




*The side door can not be higher than the middle door, or the connector will hit the door body.








10 Connect the door panel





11 Install the door panel accessories







12 Install the guide wheel






13 Install the Anti-push & pull accessories




14 Install the door panel decorative door cover



15 Install the stopper










16 Install the Cover of Track




Maintenance & Replacing

Disassemble Running Part



Maintenance & Replacing

Disassemble Running Part



Maintenance & Replacing

Replacing Activator

